

# C8D3K-STH

Air Engaged Friction Clutch  
End of Shaft Bored, Pilot Mount



## Minimum Sprocket Sizes

| Chain Size    | 50 | 60 | 80 | 100 |
|---------------|----|----|----|-----|
| Minimum Teeth | 41 | 35 | 27 | 22  |

## Engagement/Disengagement

Air/Spring

## Facing Type

High Coefficient

## Torque @ 80 PSI – Dynamic

14,855 Pound Inches

## Minimum Engagement Pressure

3 PSI

## Maximum Operating Pressure

80 PSI

## Maximum RPM

1,325

## Bore Range with Standard Keyway

2.000 (51) to 2.500 (66) Inches (mm)

## Air Volume New

5.02 Cubic Inches

## Air Volume Worn

16.53 Cubic Inches

## Finish


Aluminum

## Open or Enclosed Construction


Enclosed

## Shipping Weight

62 Pounds



## TORQUE vs. AIR PRESSURE



## NEW vs. BURNISHED TORQUE

The torque output of a new friction brake or clutch can be up to 40% less than the published torque rating. To achieve full design torque, a unit must be cycled under load to burnish the friction surfaces. The exact number of cycles varies by application.

When calculating required torque always use a safety factor of 1.5 to 2. It is not recommended to select a product for use at its maximum rated torque for continuous duty.

## PRODUCT SELECTION

Torque capacity is only one factor to consider when making a product selection. Ensure that you will have the right product for the job by contacting our engineering department for application review and selection assistance.




1580 Lake Street  
Elmira, NY 14901 USA  
859-291-0849  
machiii.com

engineering@machiii.com

# C8D3K-STH

## Parts Diagram



| REF#                  | DESCRIPTION & PARTS INCLUDED | QUANTITY | KIT NUMBER                             |
|-----------------------|------------------------------|----------|----------------------------------------|
| <b>DRIVE HUB KIT</b>  |                              |          | <b>C8D3K-STH-HUBK</b>                  |
| 1                     | Drive Hub                    | 1        | <i>Specify Bore Size When Ordering</i> |
| 2                     | Set Screw                    | 2        |                                        |
| 3                     | Retainer Ring                | 1        |                                        |
| <b>SLEEVE KIT</b>     |                              |          | <b>C8D3K-STH-SLVK</b>                  |
| 4                     | Sleeve                       | 1        |                                        |
| 5                     | Screw                        | 6        |                                        |
| 6                     | Bearing                      | 2        |                                        |
| 7                     | Retainer Ring                | 2        |                                        |
| 8                     | Ring Gear                    | 1        |                                        |
| <b>DRIVE DISC KIT</b> |                              |          | <b>C8D3K-STH-DRDK</b>                  |
| 9                     | Drive Disc                   | 2        |                                        |
| <b>REPAIR KIT</b>     |                              |          | <b>C8D3K-STH-RPRK</b>                  |
| 10                    | Friction Disc                | 3        |                                        |
| 11                    | Coil Spring                  | 12       |                                        |
| 12                    | O-Ring                       | 1        |                                        |
| 13                    | PISTON KIT                   | 1        | C8D3K-STH-P004                         |
| <b>CYLINDER KIT</b>   |                              |          | <b>C8D3K-STH-CYLK</b>                  |
| 14                    | Cylinder                     | 1        |                                        |
| 15                    | Screw                        | 6        |                                        |
| 16                    | ROTATING SEAL                | 1        | RSEAL-029                              |

### PARTS KITS

The *Repair Kit* contains common wear items for this product. Users are encouraged to stock one or more repair kits considering the number of units installed and the potential downtime if machinery on which the unit is installed is critical equipment. To obtain current pricing and lead time for parts kits, contact customer service.

[orders@machiii.com](mailto:orders@machiii.com)

### ADDITIONAL PRODUCT INFORMATION

For illustrated guides showing how Mach III products work, selection guidelines, product manuals, and installation and use recommendations:

<https://machiii.com/resources/how-our-products-work>

For information about how to order, return policy and warranty information:

<https://machiii.com/resources/how-to-order>



859-291-0849

[machiii.com](http://machiii.com)

[engineering@machiii.com](mailto:engineering@machiii.com)