



Air/Spring

Low Coefficient

2,356 Pound Inches

4.5 - 5 PSI

80 PSI

1,250

1.125 (29) to 2.250 (62) Inches (mm)


1.03 Cubic Inches

6.48 Cubic Inches

Iron

Open

90 Pounds



SPEED, RPM	HORSEPOWER
0	0.35
100	0.45
200	0.55
300	0.65
400	0.75
500	0.85
600	0.95
700	1.05
800	1.15
900	1.20
1000	1.25
1100	1.30
1200	1.35
1300	1.38
1400	1.40
1500	1.42
1600	1.44
1700	1.45
1800	1.40




1580 Lake Street
Elmira, NY 14901 USA
859-291-0849
machiii.com

engineering@machiii.com

118SI

Parts Diagram



REF#	DESCRIPTION & PARTS INCLUDED	QUANTITY	KIT NUMBER
REPAIR KIT			118SI-LOCO-RPRK
1	Friction Disc	1	
2	Coil Spring	6	
3	Diaphragm	1	
4	Screw	6	
5	Nylon Point Set Screw	1	
DRIVE HUB KIT			118SI-HUBK
6	Drive Hub	1	<i>Specify Bore Size When Ordering</i>
7	Set Screw	2	
8	Polygon Drive Adapter	1	
9	Screw	3	
SLEEVE KIT			118SI-SLVK
10	Sleeve	1	
11	Bearing	2	
12	Retainer Ring	2	
CYLINDER KIT			118PI-CYLK
13	Retainer Ring	1	
14	Bearing	1	
15	Cylinder	1	
16	Pin	2	
PISTON KIT			118SI-PSTK
17	Piston	1	
18	Bearing	1	
19	Drive Disc	1	
FACING KIT			118SI-LOCO-FCGK
1	Friction Disc	1	
4	Screw	6	
5	Nylon Point Set Screw	1	
NUT KIT			118PI-NUTK
20	Nut	1	
5	Nylon Point Set Screw	1	

PARTS KITS

The *Repair Kit* contains common wear items for this product. Users are encouraged to stock one or more repair kits considering the number of units installed and the potential downtime if machinery on which the unit is installed is critical equipment. To obtain current pricing and lead time for parts kits, contact customer service.

orders@machiii.com

ADDITIONAL PRODUCT INFORMATION

For illustrated guides showing how Mach III products work, selection guidelines, product manuals, and installation and use recommendations:

<https://machiii.com/resources/how-our-products-work>

For information about how to order, return policy and warranty information:

<https://machiii.com/resources/how-to-order>



859-291-0849

machiii.com

engineering@machiii.com